









## Cable Cutter Replacement Parts

Use the chart below to locate the model you are using. The left column lists models released before 2017. The right column lists the new models purchased 2018 and later. Contact Customer Service with any questions.

Previous Design <i>Purchased 2017 and earlier</i>			New Design <i>Purchased 2018 and later</i>		
<b>63607: Ratcheting ACSR Cable Cutter</b>			<b>63607: Ratcheting ACSR Cable Cutter</b>		
	<b>Part #</b>	<b>Description</b>		<b>Part #</b>	<b>Description</b>
	63443	Moving Blade Set		13127	Moving Blade Set
	63444	Fixed Blade Set		13134	Plastic Handle Set
	63445	Ratchet Pawl Set			
	63446	Moving Handle Set			
	63447	Fixed Handle Set			
<b>63711: Open Jaw Ratcheting Cable Cutter</b>			<b>63711: Open Jaw Ratcheting Cable Cutter</b>		
	<b>Part #</b>	<b>Description</b>		<b>Part #</b>	<b>Description</b>
		—		13114	Moving Blade Set
		—		13132	Plastic Handle Set
<b>63060: Ratcheting Cable Cutter</b>			<b>63060: Ratcheting Cable Cutter</b>		
	<b>Part #</b>	<b>Description</b>		<b>Part #</b>	<b>Description</b>
	63363	Ratchet Release Plate – 2 Step		13113	Moving Blade Set
	63364	Moving Blade Set – 1 Step		13132	Plastic Handle Set
	63365	Fixed Blade Set – 1 Step			
	63366	Ratchet Pawl Set			
	63367	Moving Handle Set			
	63368	Fixed Handle Set			
	63369	Ratchet Release Plate – 2 Step			
	63370	Fixed Blade Set – 2 Step			
63065	Spring Replacement Kit				
<b>63750: Ratcheting Cable Cutter, 750 MCM</b>			<b>63750: Ratcheting Cable Cutter, 1000 MCM</b>		
	<b>Part #</b>	<b>Description</b>		<b>Part #</b>	<b>Description</b>
	63751	Moving Blade Set		13130	Moving Blade Set
	63752	Fixed Blade Set		13132	Plastic Handle Set
	63753	Ratchet Pawl Set			
	63754	Moving Handle Set			
	63755	Fixed Handle Set			
	63756	Ratchet Release Plate			
63757	Body Spring & Guide				